

NRG 200M Wind Vane

Authors:

Technical Services





CONTENTS

INTRODUCTION 3

SENSOR IDENTIFICATION 3

POWER REQUIREMENTS 3

SENSOR MOUNTING 4

 Sensor to Mounting Boom Installation 4

NRG Mounting Boom Extension 4

LOGR SERIES LOGGER CONNECTION..... 5

 Sensor Wiring 5

 LOGR Configuration 5

SYMPHONIEPRO LOGGER CONNECTION..... 9

 Compatibility 9

 Wiring..... 10

 Channel Configuration 11

Default Scale Factors (Desktop Application 3.2.X and later)..... 11

Boom Bearing and Vane Mounting Angle..... 12

Built-in Channels 13-15 12

P-SCM Channels 20-26 13

SYMPHONIEPLUS3 LOGGER CONNECTION..... 14

 Wiring..... 14

Channels 7 and 8 14

Flex Channels 4-6 and Analog channels 9-12 14

 Channel Configuration 15

Determining Offset Value 16

SPECIFICATIONS 17




INTRODUCTION

The NRG 200M Wind Vane (introduced January, 2018) has the same form factor as the NRG 200P, and utilizes a new signal transducer which eliminates the dead band and lowers uncertainty. Additionally, sensors are individually serialized, and compatible with NRG SymphoniePRO and SymphoniePLUS3 loggers. For quality traceability, a manufacturing calibration report is available for each individual sensor.

For reliable results while using pulsed excitation on **third party data loggers**, configure the logger to record samples 150ms after excitation. If the logger does not support this configuration then revert to constant excitation.

SENSOR IDENTIFICATION

The 200M can be identified by the yellow label on the base of the body, which contains the “NRG 200M” model name, serial number (10070-NNNNNNNN), wiring information (“-”, “Signal”, “+”), and barcode.



POWER REQUIREMENTS

The 200M vane requires an excitation voltage of (4.5 to 15) V and consumes 1.5 mA of current. The terminals of the 200M are the same as the 200P, but due to the different power requirements care must be taken when connecting to a SymphoniePLUS3 logger. The EXC terminals found on the SymphoniePLUS3 vane channels 7, 8, vane SCM do not provide enough energy to power the 200M.

Logger	2.5V Pulsed EXC	5V Pulsed EXC	5V Constant EXC	12V Constant EXC
NRG SymphoniePLUS3	<i>Do not use*</i>	<i>Do not use*</i>	N/A*	18 mW
NRG SymphoniePRO	<i>Do not use*</i>	Default: 5.3 mW	7.5 mW	18 mW

***NOTE: DO NOT use the EXC terminal from a SymphoniePLUS3 logger vane channel 7, 8, or vane SCM when connecting a 200M. DO NOT use 200P sensor configuration settings on SymphoniePRO; if you do not see 200M**




in the sensor drop down list please update your Desktop Software and SymphoniePRO logger Firmware. Please review the logger specific wiring information included in this document!

SENSOR MOUNTING

The 200M utilizes a new mounting screw arrangement which achieves superior sensor to boom alignment over the previous (200P) design. The mounting process is virtually identical to the 200P.

Sensor to Mounting Boom Installation

1. Place the flexible black sensor boot onto the boom.
2. Feed the sensor signal cable up through the boot.
3. Slide the 200M onto the boom such that the set screw of the vane aligns with the flat on the sensor mounting boom. If the boom does not have a flat, position the sensor in the desired orientation.
4. Install and secure the cotter pin.
5. Tighten the sensor set screw using a #1 Philips (+) screw driver.
6. Make your sensor to cable connections as follows (use a ¼ inch nut driver to tighten the nuts)
 - a. (-) to black wire
 - b. (signal) to clear wire
 - c. (+) to red wire
7. Slide the boot up onto the sensor body.



NRG Mounting Boom Extension

Note that as of January 2018, standard NRG mounting boom sensor extensions* have been updated to provide a small flat surface for the set screw to land on. This ensures the 200M vane north mark is oriented directly in line with the side mount boom arm pointing at the tower.

**Booms updated for improved 200M Mounting (January 2018)*

NRG Mounting Boom Item	Description	Compatibility
4159	Mounting Boom 2.4m (95"), Tubular (2)	NRG 200P and 200M Vanes, NRG 40C Anemometer NRG Class 1 Anemometer
4214	Mounting Boom 2.4m (95"), Tubular (1)	NRG 200P and 200M Vanes, NRG 40C Anemometer NRG Class 1 Anemometer
9342	Boom Extension for 40C, 200P, NRG Class 1, 200M, 26.7D	NRG 200P and 200M Vanes NRG 40C Anemometer NRG Class 1 Anemometer

If using a boom with an older design for the 200P vane, the 200M can be mounted in the same way as a 200P without any modification. A table of boom item numbers has been included for convenience.



LOGR-SERIES LOGGER CONNECTION

The NRG 200M Wind Vane is compatible with LOGR|Solar (NRG item# 9432). Beginning with firmware version 1.12.02 and later (November 2025), the LOGR|Solar vane configuration process closely follows the SymphoniePRO configuration process. Previous LOGR|Solar firmware versions present differently within the web UI but are still compatible with the 200M Wind Vane.

Please update the logger firmware before performing sensor configurations and/or data processing tasks. The latest version of LOGR|Solar firmware can be found on the [NRG Systems website, here.](#)


Sensor Wiring

Please reference the table below to connect the NRG 200M Wind Vane to a LOGR|Solar analog port using the supplied cable.


200M Connection	Color	LOGR Solar Connection
+	Red	A1 to A7 EXC
Signal	Clear	A1 to A7 SIG+ or SIG- (SIG + for odd numbered channels, SIG- for even numbered channels)
-	Black	A1 to A7 GND

LOGR Configuration

1. Navigate to the **Sensors** menu and select **Analog Channels** from the dropdown options.



2. Click the grey **Configure** button for the channel you wish to connect to the 200M. Note the port number should match the port you connected the vane to ("A1").





3. Select the **NRG 200M Vane** from the **Sensor Type** dropdown menu.

Analog Channel Configuration

Port A1-Ch 1

Enable Configuration

☒ Enabled

Sensor Type	Description	Units	Slope	Offset
NRG 200M Vane	NRG 200M Vane	Deg	147.91100	-1.46020
NRG 200M Vane	Height (m)	Elevation Angle	Boom Bearing (Deg) ⓘ	Modbus Address
Atonometrics RC18 Irradiance	0.00	0	0.0	10028
Atonometrics RC18 Temperature				
Hukseflux SR05-D1A3				
NRG Grid Monitor (0 to 30)V				
NRG R1				
NRG Soiling 300V				
NRG Soiling 30A				
Kipp & Zonen SUV5-V				
IMT Si-V-1.5TC-T Irradiance				
IMT Si-V-1.5TC-T Temperature				
PSM NRG-30W IscSoil				
PSM c-Si Isc Soil				

Gust Source Channel


No Sensor

Back Reset Done

4. Complete the sensor parameter fields to finalize sensor configuration. The default **Slope** and **Offset** should be maintained unless the sensor utilized is a calibrated wind vane. In that case, the information should be pulled from the calibration certificate.

Importantly, input the sensor **Serial Number**, and **Height** of the sensor above ground, in meters. **Elevation Angle** *DOES NOT APPLY* to wind vanes; this parameter is used for sensors that can be mounted on a tilted axis such as a plane of array (POA) pyranometer.


Boom Bearing works in conjunction with the **Vane Mounting Angle** and indicates the sensor boom orientation in positive degrees relative to true north. Shown below is an example installation where the side mount boom for the NRG 200M Wind Vane is attached to the tower at a bearing of 50 degrees. In this situation, a value of 50 is placed in the **Boom Bearing** field.




Vane Mounting Angle works in conjunction with the **Boom Bearing** field and defines the angle of the “North Mark” on the vane relative to the mounting boom.

A **Vane Mounting Angle** of 0 degrees indicates the sensor north mark is pointing away from the boom and tower. A **Vane Mounting Angle** of 180 degrees indicates the sensor north mark is directly pointing towards the boom and the tower.

The diagram below shows the north mark located on the base of the 200M Wind Vane. The vane has a cotter pin and setscrew mounting system. NRG Side Mount Booms have a hole to accept the cotter pin. The cotter pin runs perpendicular to the length of the boom such that the vane can either be installed with the north mark pointing away from the tower (vane mounting angle of 0) or with the north mark pointing towards the tower (vane mounting angle of 180).



The image below illustrates a top-down view of the vane boom mounted with the sensor north mark pointing away from the tower. In this example, the boom bearing is 50 degrees and the vane mounting angle is 0 degrees. The logger must be configured with those values to provide the correct wind direction for the sensor installation.





Use the **Gust Source Channel** dropdown menu to select the wind speed sensor (anemometer) configured on this logger to pair the data collected for wind speed and direction.

Note: Wind gust is the highest 3-sec average wind run per data time interval and is used for structural loading calculations. Pairing a direction channel to a wind speed channel allows the user to determine the direction from which a gust originates.

Analog Channel Configuration

Port A1-Ch 1

Enable Configuration

☒ Enabled

Sensor Type	Description	Units	Slope	Offset
NRG 200M Vane	NRG 200M Vane	Deg	147.91100	-1.46020
Serial Number	Height (m)	Elevation Angle	Boom Bearing (Deg) ⓘ	Modbus Address
1007000000111	0.00	0.0	0.0	10028
Vane Mounting Angle ⓘ	Gust Source Channel			
180.0	402-NRG 40 Anemometer			

Back

Reset

Done

LOGR firmware versions prior to 1.12.02 did not display fields for **Boom Bearing** or **Vane Mounting Angle**. Instead, **Azimuth** field was shown. The Azimuth field contains the direction for which the vane north mark was pointing. In this case, the Azimuth field would have the value of 50, since the compass direction relative to truth north the vane north mark is pointing is 50.

SYMPHONIEPRO LOGGER CONNECTION

Compatibility

The NRG 200M Wind Vane is compatible with SymphoniePRO Desktop Application 3.2.X and later (3.5.1 and later recommended); and logger firmware 2.3.1 and later.

NOTE: Please update your desktop software and logger firmware before performing logger configuration and/or data processing tasks. The latest versions of software, firmware and documentation can be downloaded from this page: <https://www.nrgsystems.com/services-support/resources/documentation-and-downloads/>.




Wiring

Wiring the NRG 200M to the SymphoniePRO is straight forward and familiar. Please follow the tables below.


Built in Channels 13-15

<i>Channels 13 - 15 (no SCM required)</i>		
200M Connection	Color	SymphoniePRO Logger
+	Red	Connect to 13-15 "EXC" terminal
Signal	Clear	Connect to 13-15 "SIG" terminal
-	Black	Connect to 13-15 "GND" terminal



P-SCM Channels 20-26

<i>Channels 20-26 (use P-SCM #9130)</i>		
200M Connection	Color	SymphoniePRO Logger
+	Red	Connect to 20-26 "EXC" terminal
Signal	Clear	Connect to 20-26 "SIG" terminal
-	Black	Connect to 20-26 "GND" terminal



Channel Configuration

Create the following configuration in the SymphoniePRO Desktop Application (Version 3.2.X or later). Note, if you do not see the 200M in the “Load From Defaults” drop-down menu, please update your software from the “Services and Support” section of our website (<https://www.nrgsystems.com>).

Default Scale Factors (Desktop Application 3.2.X and later)

The SymphoniePRO Desktop Application contains default scaling information for the 200M wind vane. It is also possible to configure using other scaling information such as from an individual sensor’s calibration report.

- Scale Factor: 147.91
- Offset: -1.460




Boom Bearing and Vane Mounting Angle

SymphoniePRO has configuration fields not found in previous NRG loggers such as the SymphoniePLUS3. The **Boom Bearing** field indicates the sensor boom orientation in positive degrees relative to north. This field can also be used to factor in the magnetic declination (site specific variation between magnetic north and true north:

<http://www.ngdc.noaa.gov/geomag-web/>).

In addition to the Boom Bearing field, there is the option to enter a **Vane Mounting Angle** for wind vane channels. Vane Mounting Angle defines the angle of the “North Mark” on the vane relative to the boom. Zero degrees indicates the mark is facing away from the boom and tower; 180 degrees indicates that the mark is directly facing the boom and the tower.

An explanation of the Boom Bearing and Vane Mounting Angle is available by hovering over the Vane Mounting Angle tooltip in SymphoniePRO Desktop Application.



Built-in Channels 13-15

The 200M can be installed on logger channels 13-15 without the need for a P-SCM. Choose “NRG 200M Wind Vane” from the “Load From Defaults” drop down menu.

Analog 2.500 V or 5 V Excitation

13 Statistics Wind Vane w/Offset NRG 200M Vane 10070-00000379 60.00m 90.0 ° (E)

Data Logging Mode Load From Defaults Statistics

Channel Type Wind Vane w/Of

A channel of type Wind Vane w/Offset is compatible with wind vanes which can be powered by a pulsed 5 V, and allows a sensor-specific Scale Factor and Offset to be entered.

Records the following statistical wind direction information:

- Average (unit vector method)
- Standard Deviation (Yamartino Method)
- Direction of maximum gust (Channel 13 detects maximum gust with channel 1)

Description NRG 200M Vane

Serial Number 10070-00000379

Height 60 Meters

Boom Bearing 90 Degrees

Vane Mounting Angle 180 Degrees

Excitation

Mode Constant On

Voltage 5 V

Dead Band Compensation

North East 0 Degrees

North West 0 Degrees

Scale Factor 147.911 Degrees per V

Offset -1.4602 Degrees

P-SCM Channels 20-26

Part Number	Input Type	Excitation Voltage
9130	0-5V SE Input	5V Pulsed
9131	0-5V SE Input	12V Pulsed
9132	0-5V SE Input	12V Constant
9410	0-5V SE Input	5V Constant

Analog (P-SCM)

— 20 Statistics Wind Vane w/Offset NRG 200M Vane 10070-00000380 60.00m 270.0 ° (W)

Data Logging Mode Statistics ▼

Channel Type Wind Vane w/Of ▼

A channel of type Wind Vane w/Offset is compatible with wind vanes which can be powered by a pulsed 5 V, and allows a sensor-specific Scale Factor and Offset to be entered.

Records the following statistical wind direction information:

- Average (unit vector method)
- Standard Deviation (Yamartino Method)
- Direction of maximum gust (Channel 20 detects maximum gust with channel 8)

Description NRG 200M Vane

Serial Number 10070-00000380

Height Meters

Boom Bearing Degrees ⓘ

Vane Mounting Angle Degrees ⓘ

SymphoniePRO Signal Conditioning Module (P-SCM)

P-SCM #9410, (0 to 5) V, SE Input, Constant 5V EXC ▼

Dead Band Compensation ⓘ

North East Degrees

North West Degrees

Scale Factor Degrees per V

Offset Degrees



SYMPHONIEPLUS3 LOGGER CONNECTION


Wiring

Channels 7 and 8

- Signal and GND are wired as normal, connect to analog channel 7 or 8.
- EXC can be connected from digital-counter channels 1-3, or 13-15 (this supplies constant 12 V to the 200M)

NOTE: Do NOT connect the EXC to channel 7 or 8!

Channels 7 and 8 (no SCM required)		
200M Connection	Color	SymphoniePLUS3 Logger
+	Red	Connect to channel 1-3, 13-15 "EXC" terminal
Signal	Clear	Connect to channel 7-8 "SIG" terminal
-	Black	Connect to channel 7-8 "GND" terminal



Flex Channels 4-6 and Analog channels 9-12

Signal and GND are wired into a channel with wind vane SCM (#3152) present; either a flex channel 4-6, or an analog channel 9-12.




Sensors | 200M Wind Vane

- Signal and GND are wired as normal, connect to analog channel 7 or 8
- EXC can be connected from digital-counter channels 1-3, or 13-15 (this supplies constant 12 V to the 200M)

NOTE: Do NOT connect the EXC to channel 7 or 8!

Channels 4-6, 9-12 (requires SCM 3152)

200M Connection	Color	SymphoniePLUS3 Logger
+	Red	Connect to channel 1-3, 13-15 "EXC" terminal
Signal	Clear	Connect to channel 4-6, 9-12 "SIG" terminal
-	Black	Connect to channel 4-6, 9-12 "GND" terminal



Channel Configuration

The 200M has a different default scaling than the 200P. *Do not use the 200P settings found in SDR!*

Instead, configure as follows:

- Slope: 0.368
- Offset: -5.3 (see section below about integrating boom direction into offset)



Determining Offset Value

North Mark Pointing Away from Tower

If the boom heading is pointing in a direction other than North (0 degrees) and the north mark of the 200M is facing away from the tower, calculate your overall offset as follows:

- **Offset = Boom Heading – 5.3**
 - **Example:** Boom Heading is 90 Deg (East) and the North Mark on the vane is pointing away from the tower.
 - Offset = 90 – 5.3
= 84.7

North Mark Pointing Toward Tower

If the boom heading is pointing in a direction other than North (0 degrees) and the north mark of the 200M is facing toward the tower, calculate your overall offset this way:

- **Offset = Boom Heading + 180 - 5.3**
 - **Example:** Boom Heading is 90 Degrees (East) and the North Mark on the vane is pointing toward the tower.
 - Offset = 180 + 90 – 5.3
= 264.7



SPECIFICATIONS

Please see nrgsystems.com for up to date product specifications.

Description	Sensor type	Continuous rotation wind direction vane
	Applications	Wind resource assessment Meteorological studies Environmental monitoring
	Sensor range	360° mechanical, continuous rotation
	Instrument compatibility	All Symphonie Data Loggers
	Measurement range	0 - 360°
Output signal	Signal type	Analog DC voltage
	Linearity	0.1°
	Transfer function	<p>SymphoniePRO*:</p> <p>Default slope = 147.91°/V</p> <p>Default offset = -1.460°</p> <p>SymphoniePLUS3*:</p> <p>Default slope = 0.368°/V</p> <p>Default offset = -5.3°</p> <p>Individual sensor transfer function is available via factory calibration certificate.</p>
	Dead band	None



	Calibration	Each sensor is individually factory calibrated. Factory calibration certificates provided via electronic download.
	Output signal range	0.007Vdc to 2.5Vdc
	Uncertainty	Expanded uncertainty (k=2) 95% confidence [Sensor only]: +/-1.6° (>0.9° to <359.1°) +/-2.5° (359.1° to 0.9°)
Response characteristics	Threshold	1.5 m/s (3.35 mph) @+/-10°, 0.97 m/s (2.16 mph) @+/-90° per ASTM D5366-96
	Delay distance	1.18 m (@5 m/s), 1.20 (@10 m/s) per ASTM D5366-96
Power requirements	Supply voltage	4.5 Vdc to 15 Vdc
	Supply current	1.5mA
Installation	Mounting	Onto a 13 mm (0.5") diameter mast with cotter pin and #2 phillips set screw. *Note: Use of NRG boom extension with alignment feature provides standardized set screw landing location and sensor orientation.
	Tools required	#1-Phillips driver, 0.25" nut driver, petroleum jelly, electrical tape
Environmental	Operating temperature range	-40°C to 60°C (-40°F to 140°F)
	Operating humidity range	0 to 100% RH
Physical	Connections	4-40 nickel plated brass hex nut/post terminals
	Weight	0.108 kg (0.238 pounds)



	Dimensions	21 cm (8.3 inches) length x 12 cm (4.3 inches) height 27 cm (10.5 inches) swept diameter
Materials	Wing	Black UV stabilized injection-molded plastic
	Body	Black UV stabilized static-dissipating plastic
	Shaft	Stainless steel
	Bearing	Stainless steel
	Magnet	Neodymium
	Boot	Protective PVC sensor terminal boot included
	Terminals	Nickel plated brass